



V8 Motor Tower Instructions

Note: Motor Towers should be mounted with center hole 11" back from rear edge of front cross member.

