



## TBP Custom Seats Installation

Step 1: Remove old seats and brackets

Step 2: Mount new seat brackets to sliders using allen-head bolts. Putting the head of the bolt in the valley of the slider track. Refer to the picture to determine the orientation of seat brackets. You will have to slide the tracks all the way forward and then all the way back to access the bolt holes.

Step 3: After brackets are mounted on sliders, bolt seat brackets down (hand tight) into factory hole locations using 5/16" washer head bolts. The back two holes on the passenger side will have to be drilled, so mark those holes and then remove the seat. Drill these holes with a 5/16" drill bit. After all the bolts are hand tightened and seats are installed, use a 1/2" wrench or socket and tighten to 19 ft lb.

If you have any questions, please refer to our video at the following web address:

[www.tomsbroncoparts.com/pages/instructional-videos/how-to-install-tbp-deluxe-vinyl-denim-seats/](http://www.tomsbroncoparts.com/pages/instructional-videos/how-to-install-tbp-deluxe-vinyl-denim-seats/)



*Illustration 1: Passenger Seat Bracket Installed*



*Illustration 2: Driver Seat Bracket Installed*